

**Audi**

Please give copies to
all your Audi Technicians

Important! Technical Bulletin

Vehicle Delivery Information

Subject: **Transport Mode, Deactivating When Vehicle Arrives at the Dealership** Group: **00**

Number: **05-01**

Model(s): **All-new A4, S4
Avant, Sedan**

2005 from VIN: 8E_5_400001, 2006 Date: Feb. 14, 2005

Condition

When vehicle is in transport mode AND the auto-lock function of the central locking system is active (default when leaving the factory). The sleep current of the Convenience System Central Control module -J393- may be too high. This increased sleep current may drain the vehicle battery.

Service

Until further notice, please adhere to the following procedure for handling the All-new Audi A4 when vehicle is first received at the Dealership:

- Immediately disable Transport Mode using the VAS 5051/5052 Diagnostic tool.



Tip:

- ◆ *Increased sleep current only occurs while Transport Mode is active and therefore will not inconvenience the customer.*
- ◆ *This is a temporary measure in order to avoid batteries being drained during transport and storage.*